



kate spade

NEW YORK



KATE SPADE NEW YORK
WATCHES INSTRUCTION MANUAL

*please visit our website for the latest instruction details,
warranty and service center information*





*kate spade new york watches are made of 100%
hypoallergenic stainless steel.*

BATTERY LIFE

the battery of your kate spade new york watch should last approximately two years. please be sure to replace it as soon as it expires to prevent any malfunction or damage to the piece.



LEATHER STRAPS

our leather straps are made with the finest materials. keep it in pristine condition by shielding it from direct sunlight for prolonged periods, which can cause fading. also, do not submerge in water.





WATER RESISTANCE

- be sure the crown is pushed in completely before using your watch in or near water.
- if the watch is underwater or wet, do not use the crown and wipe it dry as quickly as possible.
- steam may compromise its water resistance, so it is best to keep it away from hot tubs, saunas or hot showers.
- water resistance may decrease over time and with wear and tear, so please use caution.
- always keep leather straps away from water.






*splash,
rain,
hand*


<i>marking</i>	<i>washing</i>	<i>swimming</i>	<i>snorkeling</i>	<i>scuba</i>
—	NO	NO	NO	NO
3 ATM	YES	NO	NO	NO
5 ATM	YES	YES	NO	NO
10 ATM	YES	YES	YES	NO



INSTRUCTIONS FOR 3 HAND MOVEMENT



A B C



SECOND HAND



TO SET THE TIME

1. pull out crown completely to last position.
2. turn crown counterclockwise to correct time.
3. push in to position A.

TO SET THE DATE

(for watches with a calendar window)

1. pull out crown to middle position B.
2. turn crown counterclockwise to correct date.
3. push in to position A.

TO SET THE DAY


(for watches with a day window)

1. pull out crown to middle position B.
2. turn crown clockwise to correct day.
3. push in to position A.





INSTRUCTION MANUAL FOR 3-EYE CHRONOGRAPH MOVEMENT







TO SET THE TIME

1. pull the crown out to the 1st click position **B**.
2. turn the crown to set the hour and minute hands.
3. when the crown is pushed back to **A**, second hand begins to run.

TO USE THE STOPWATCH



this stopwatch is able to measure and display time in 1 second unites up to a maximum of 29 min, 59 sec. stopwatch will stop automatically after running continuously for 30 minutes.




MEASURING TIME WITH THE STOPWATCH

1. press button **C** to start the stopwatch.
2. the stopwatch can be started and stopped each time button **C** is pressed.
3. pressing button **D** resets the stopwatch and returns the stopwatch minute and second hands to their zero positions.




BANGLE INSTRUCTIONS



to open, press the tip of the spade

DIGITAL INSTRUCTIONS





*the digits show display hour, minute, second
(date, month) and LCD turn on/off function*



WATCH FEATURES

- digits display hour & minute (in the default time display), month & day (in date display) or seconds (in second display)
- buttons **A** and **B** turn LCD on and off

WATCH FUNCTIONS & ADJUSTMENTS

- 
- 
- to turn off the LCD, press **B** for 3 seconds until the LCD screen turns off.
 - to turn on the LCD, press any button for .5 seconds.
 - the watch will automatically display the time. to view the date or seconds, press **B**.
- note that the screen will automatically return to the time display after 10 seconds of inactivity.



TO ADJUST THE TIME

time – press **A** until the digits begin to blink.
adjust the hour and minute by pressing
B. don't forget to select “a” (for am) or
“p” (for pm) to indicate the time of day.



TO ADJUST THE DATE



date – press **A** until the digits begin to
blink. bypass the time setting by pressing
A until the date digits appear. adjust
the month and day by pressing **B**.

note that the watch will automatically revert back
to time display after 1 minute of inactivity.

